



Please Note: This sensor *must* be used with a Galvanic Isolation Amplifier - See X005 sheet for Output options.