

A005 ANZEx Galvanic Isolation Amplifier	Part Number Coding		
	A005		suffix

Electrical Interface Options		
For use with Intrinsically Safe Sensors coded Z000		
Input from Sensor	Output from Amplifier	suffix
0.5 to 4.5V	4-20 mA	425
0.5 to 4.5V	20-4 mA	426
0.5 to 4.5V	0.5 to 9.5V	545
0.5 to 4.5V	9.5 to 0.5V	546
Direct replacements for BX002/BX003 barriers		
replacement for	Output from Amplifier	suffix
BX002	0.5 to 9.5V	010
BX003	4-20 mA	420
For use with Potentiometers		
Input from Potentiometer	Output from Amplifier	suffix
0 to 5V	0.5 to 9.5V	001
0 to 5V	9.5 to 0.5V	002
0 to 5V	4-20 mA	003
0 to 5V	20-4 mA	004